
Guess Row Optimization

- 1. Make sure the height value is correct in the receiver setup page
- 2. Confirm the proper machine AND implement dimensions are entered correctly. Pay attention to lateral offsets, if any.
- 3. Calibrate the TCM. This is usually the issue.
- 4. Confirm the tractor itself is driving the proper track spacing. Remember to keep a realistic expectation for AutoTrac pass-topass accuracy. See right for specs. ATU performance will be less than machines with steering valves.
- 5. Check the implement. An implement may not pull straight for many reasons: uneven adjustment, wear, or depth across the tool, hilled terrain, or uneven soil type across tool.
- 6. If the implement is pulling consistently to one side, a lateral offset can be entered in the <u>implement</u> dimensions. If it's pulling to the left, put in an appropriate offset to the left in the implement dimensions. Process for calculating offset is below.
- 7. If the tool is very wide, and puling from side-to-side inconsistently, the tool may require implement steering.

StarFire 3000 - Main	SN: 3338 Serial	F Note and and a second
Info Setup	Activations Port	
Correction Mode SF2	Enable Optimize Shading	
Default Correction freq 1545.5450 Mount Direction	Hours On After Shutdown	
Forward Fore/Aft (in) 80	On C	
Height (in)	Last Calibration.	3:50pm

Correction Signal	SF3000	SF6000
SF1	+/- 9"	+/- 5.9"
SF2	+/- 2"	n/a
SF3	n/a	+/- 1.2"
RTK	+/- 1"	+/- 1"



Planting: process for determining offset:

- a. Drive three passes (see diagram above)
- b. Measure the Narrow guess row and Wide guess row
- c. Calculate the offset from desired for both.

$$Narrow\ Offset = \left(\frac{Desired-Narrow}{2}\right)$$

$$Wide\ Offset = \left(\frac{Wide\ -\ Desired}{2}\right)$$

- d. The Narrow and Wide offsets should be the same, or within an inch. If not, re-calibrate the TCM.
- e. Take the average of the Narrow and Wide offsets and enter into the lateral dimension for the implement. Make sure to enter the lateral offset on the correct side.
- f. For tillage, measure the <u>overlap</u> and the <u>gap</u>. Substitute the overlap for the "Desired Narrow" number, and the gap for the "Wide desired" number in the equations to the left. Follow steps d to e.

